
Alignment Process

PinMate displays two opposing target cavities for alignment. Operator drags and drops the targets into place.

Click the down arrow to move to the next page





Spare Pins & Seal Plugs

2 Add the spare pins and sealing plugs (if applicable).

Click the down arrow to move to the next page



Inserting Wires

Operator enters a wire ID and inserts a wire.

Click the down arrow to move to the next page





Process Completed

4 Process continues until the connector is fully pinned.

